

USE CASE - solution


Insert the stream from an IP camera into your TV distribution as a TV channel

The following article will provide you with instructions on how to easily add an H.264 video stream from your AXIS IP camera directly into the program selection of your television. This solution is great for establishments such as hotels, where you can have a stream on the TV in each room. With the [CamStreamer App](#), you can also stream it to the internet, and with the [CamOverlay App](#) you can put other interesting information into video such as current weather info / forecast, a promo text, or infoticker. Another usage is for example the broadcast of church services to hospital rooms or in senior-citizen homes and also as a security channel in residential housing.

In our solution, we work with DVB-T, which means Digital Video Broadcasting – Terrestrial; it is the DVB European consortium standard for the broadcast transmission of digital terrestrial television. In the U.S., ATSC standard is used, and in this case you will need a different HDMI modulator (for example a [PVI VeCOAX MiniMod-2](#), which can modulate into **ATSC, QAM, DVB-T, DVB-C and ISDB** as well).

Necessary HW:

- Any Axis camera – an [Axis P1375](#) is used in the example
- [NetcamViewer Monitor](#) – for transferring 1 to 4 cameras from a local network to an HDMI interface
- [Edison HDMI modulator](#) – for inserting an HDMI source into the multiplex of a DVB-T signal
- Any TV with a DVB-T tuner or an independent DVB-T tuner



Set-up steps:

- 1) Plug in the NetcamViewer Monitor and also connect it via ethernet cable to the local network containing your IP camera.
- 2) Connect the NetcamViewer Monitor via HDMI interface to your television or monitor – on the screen, you'll see the IP address on which the device is located.
- 3) In the NetcamViewer Monitor's interface, add your camera simply via camera type, or (if you also want audio and to change other parameters) via the "Manual (Advanced) option".
- 4) After adding a camera, click on the "Play" icon in the camera preview and check the video and audio on your television. If everything is correct, continue on in settings.



USE CASE - solution

Insert the stream from an IP camera into your TV distribution as a TV channel


Adding a camera via Manual (Advanced) mode:

a) Enter the following address into the RTSP Path field:

```
rtsp://root:pass@192.168.100.103/axis-media/media.amp
```

- in the address, replace your camera password (pass) and the camera's actual IP address.

b) Enter - `audio=1&compression=0` in the Extra URL Parameters field - a value of 1 adds audio to video and compression with a value of 0 sets the lowest video compression.



Manual (Advanced)	
Name	Camera with audio
JPEG Path	http://
RTSP Path	rtsp://root:pass@192.168.100.103/axis-media/media.amp
MJPEG Path	http://
Extra URL Parameters	audio=1&compression=0

- 5) Plug in the Edison HDMI modulator and connect an antenna with a DVB-T signal to its input.
- 6) Connect an HDMI output of the NetcamViewer Monitor to an HDMI input of the Edison modulator.
- 7) On the modulator, confirm a free channel in the DVB-T multiplex and its name (distortion/pixelation of the image may occur if there is overlap with an existing channel). If necessary, set additional parameters according to the modulator manual.
- 8) Connect the output antenna from the modulator into the television with a DVB-T tuner, retune all channels, and browse to a program from the modulator (default name is "TV-1")



Your stream can be enriched with local information via the [CamOverlay App](#). This can include features such as local weather downloaded from the AccuWeather server or an InfoTicker with your own text.

And finally, you can also run the [CamStreamer App](#) on your IP camera and stream to platforms such as YouTube, Facebook, DaCast, Wowza, etc.



USE CASE - solution

Insert the stream from an IP camera into your TV distribution as a TV channel

Need help?

Contact us at
support@camstreamer.com

